

Assembly

Base Assembly

Step 1.

Insert S03 (Hex-head bolts) into the W05A's, and additional W05A's or W05B's if you haves an additional mounting kit, and L640's corner stakes or brackets, then wind an M01 (Hex-head nut) onto the thread (a couple of turns only) of each S03. The L640-0300 are the corner stakes that come with the greenhouse, and are designed to go into the ground. The L640-0080 are 80mm corner joiners that come with the mounting kits, if you purchased one. Refer to the diagram on page 9 for bracket placement.

Ensure the nuts are not tightened as they should be left loose to enable them to slide into position.



Base Dimensions and Bracket Configuration PG0606

